

Web conferences from the lecture hall

(Media control TYP E2)

Switch on media technology



Switch on the media technology, the lecture hall PC and the microphones. Log in to the lecture hall PC with your student or university ID GWDG domain).

The „Videokonferenz“ scenario can only be used for Cisco video conferences. Web conferences via the PC (Zoom, Big-BlueButton, ...) do not work with this very scenario.

Camera control




You open the camera control by clicking on the camera symbol in the lower menu bar. In this menu you can select the desired image section. For the computer to receive an image, the „Kamera auf Vorschau“ option must be activated. This image is also used in the video conference.

Select preset camera position

Image section change (select camera)

Here you define how fast the camera image should change when the camera section and the zoom are changed. If the value set here is too low, nothing will happen.



Here you define which camera is displayed on the preview monitor (monitor on the lectern). This signal is sent to the PC as a camera signal and can therefore be viewed as a webcam in the web conference. So that a camera image arrives at the PC, „Kamera auf Vorschau“ must be activated and the camera image must be visible on the preview monitor.

Zoom in/out

Camera icon in the menu bar

Display



Select which image is displayed on which screen. Please note that the preview monitor must show „Zuschauer-/Doz.-kamera“ and that „Konferenz Main“ and „Konferenz Second“ are only used for Cisco video conferences.

Microphone



Use the microphones as usual. Everything that can be heard via the loudspeakers is transmitted to the PC. I.e. several microphones can be used at the same time.

Start web conference on PC

Start the web conference as usual from the lecture hall PC. Normally, the microphone source should already be correctly preset. The speaker in the web conference for the audio output should also already be selected. If this is not the case, please select the correct devices. You can determine these by trial and error if necessary, as the designations vary slightly between the individual rooms.



Scan QR code for detailed instructions and additional information.